

Coil Ear Stiffener installation instructions for Minelab Equinox series



DETECTING DOODADS
3D PRINTED PRODUCTS FOR METAL DETECTING ENTHUSIASTS

- 1 Loosen and remove coil nut and bolt. Remove lower shaft by pulling straight up.
- 2 Slide ear stiffener over coil ears.
- 3 Push lower shaft straight down until it bottoms out on the stiffener.
- 4 Install coil nut and bolt. Tighten to desired tightness.

